

# OXYDrive™

## INSTALLING BOTTOM BRACKET PEDAL SENSOR

### STEP 1

Remove the left crank arm with crank puller



### STEP 2

Slot the PAS sensor on the square taper shaft



### STEP 3

Insert the PAS sensor into bottom bracket's holding nut. Please note the teeth may not always fit on all types of bottom brackets. These may need to be slightly modified or filed off.



### STEP 4

Put the crank arm on the shaft and screw it back



PLEASE NOTE: The shown above PAS sensor is not a standard component that comes with OXYDrive kits. Generally it should be fitted on the left arm to allow less complex installation of the kit.